9.9 Lab: Poison DNS

Candidate: COMPTIA COMPTIA ()
Time Spent: 01:07

Score: 0%	

Task Summary

Required Actions

- ★ Scan for hosts in Ettercap
- X Set Exec as the target machine and initiate DNS spoofing
- X Confirm the redirection to Exec

Explanation



Complete this lab as follows:

- 1. From the Support computer, use Ettercap to begin sniffing and scanning for hosts.
 - a. From the Favorites bar, select **Ettercap**.
 - b. Select **Sniff** > **Unified sniffing**.
 - c. From the Network Interface drop-down menu, select enp2s0.
 - d. Select **OK**.
 - e. Select Hosts >Scan for hosts.
- 2. Configure the Exec computer (192.168.0.30) as the target 1 machine.
 - a. Select **Hosts** > **Host list**.
 - b. Under IP Address, select 192.168.0.30.
 - c. Select **Add to Target 1** to assign it as the target.
- 3. Initiate DNS spoofing.
 - a. Select Plugins > Manage the plugins.
 - b. Select the **Plugins** tab.
 - c. Double-click **dns_spoof** to activate it.
 - d. Select Mitm > ARP poisoning.
 - e. Select **Sniff remote connections** and then select **OK**.
- 4. From the Exec computer, access rmksupplies.com.
 - a. From the top left, select Floor 1 Overview.
 - b. Under Executive Office, select Exec.
 - c. From the taskbar, select Google Chrome.
 - d. In the URL field, type **rmksupplies.com** and then press **Enter**.

 Notice that the page was redirected to RUS Office Supplies despite the web address staying the same.