

12.7 Lab: Secure an Enterprise Wireless Network

Candidate: COMPTIA COMPTIA ()

Time Spent: 00:15

Score: 0%

Task Summary

Required Actions

-
- ✕ Change admin username and password [Show Details](#)
-
- ✕ Enable MAC address filtering [Show Details](#)
-
- ✕ Configure access controls [Show Details](#)
-

Explanation

To complete this lab, use the following MAC addresses:

- 00:18:DE:01:34:67
- 00:18:DE:22:55:99
- 00:02:2D:23:56:89
- 00:02:2D:44:66:88

Complete this lab as follows:

1. Log into the Ruckus Wireless ZoneDirector.
 - a. In the Google Chrome URL field, type **192.168.0.6** and press **Enter**.
 - b. Log in using the following:
 - Admin Name: **admin**
 - Password: **password**
 - c. Select **Login**.
2. Change the admin's username and password for the Ruckus Wireless ZoneDirector.
 - a. Select the **Administer** tab.
 - b. Ensure **Authenticate using the admin name and password** is selected.
 - c. In the Admin Name field, enter **WxAdmin**
 - d. Enter **password** in the Current Password field.
 - e. In the New Password field, enter **ZDAdminsOnly!\$** (Note: O is the capital letter O).
 - f. Enter **ZDAdminsOnly!\$** in the Confirm New Password field.
 - g. On the right of the section, select **Apply**.
3. Enable MAC address filtering.
 - a. From the top, select the **Configure** tab.
 - b. From the left menu, select **Access Control**.

- c. Expand **L2-L7 Access Control**.
 - d. Under *L2/MAC address Access Control*, select **Create New**.
 - e. In the Name field, enter **Allowed Devices**.
 - f. Under Restriction, make sure **Only allow all stations listed below** is selected.
 - g. Enter a **MAC address**.
 - h. Select **Create New**.
 - i. Repeat steps 3g–3h for each of the remaining MAC addresses that need to be added to the ACL.
 - j. Select **OK**.
4. Configure access controls.
- a. Under Access Control, expand **Device Access Policy**.
 - b. Select **Create New**.
 - c. In the Name field, enter **NoGames**.
 - d. Select **Create New**.
 - e. Use the OS/Type drop-down menu to select **Gaming**.
 - f. Use the Type drop-down menu to select **Deny**.
 - g. Under Uplink, ensure **Disabled** is selected.
 - h. Under Downlink, ensure **Disabled** is selected.
 - i. Select **Save**.
 - j. Select **OK**.