Complete this lab as follows:

- 1. Replace the cable on the Office1 computer
 - 1. From the top left, select **Floor 1** to view the map of the offices.
 - 2. On the map, select **Hardware** under Office 1 to view the computer hardware in that office.
 - 3. Drag the networking cable out of the wall plate and drop it on the workspace.
 - 4. Above the Office1 workstation tower, select the **Back** button.
 - 5. Drag the other end of the networking cable from the back of the workstation and drop it on the workspace.
 - 6. Drag a Cat6a cable from the **Shelf** to the wall plate to connect one end.
 - 7. Drag the other end of the same cable to the back of the workstation and plug it into the motherboard.
 - 8. Click the computer monitor where it says **Click to view Windows 11**. Notice that the networking icon shows no internet connection.
- 2. Check the physical connection of the cables on the switch for the Office1 computer.
 - 1. From the top left, select **Floor 1**, then select **Hardware** in the Networking Closet.
 - 2. Zoom in close to the switch and patch panel in the hardware rack (the second and third items from the top of the rack).
 - 3. On the patch panel, select the cable under the label **Off 1** (for Office 1). Notice that the other end is highlighted in the switch in port number 3. As you can see, the port does not show a link light or any activity.
- 3. Check the configuration of the switch in the Networking Closet.
 - 1. From the top left, select **Floor 1**, then select **ITAdmin** in the IT Administration office.
 - 2. Select the **Chrome** icon on the taskbar.
 - 3. Access the switch management console from the ITAdmin computer using the following credentials:
 - Address: http://192.168.0.2 (maximize the Chrome window)
 - Username: ITSwitchAdmin (case-sensitive)
 - Password: Admin\$only (case-sensitive)
 - 4. From the left menu in the switch management console, select **Port Management**.
 - 5. From the Port Setting Table, notice that port 3 is listed as *Down* under Operational Status.
 - 6. Select port 3, then scroll to the bottom and select Edit.
 - 7. Change the Administrative Status to **Up**.
 - 8. Select Apply.
 - 9. Select Close.