Complete this lab as follows:

- 1. Add the media converter to the rack.
 - 1. Under Shelf, expand **Networking Devices**.
 - 2. Drag the *Media Converter* to the bottom shelf of the rack in the Workspace.
- 2. Connect the SC to LC fiber cable to the media converter.
 - 1. Above the rack, select **Back** to switch to the back view of the rack.
 - 2. Drag the *Ethernet cable* from the *left* wall outlet to the Ethernet port on the media converter.
 - 3. Under Shelf, expand Cables.
 - 4. Select the Cable, Fiber, SC to LC cable.
 - 5. From the Selected Component pane, drag the *Connector, Fiber Duplex LC* male connector to the media converter.
- 3. Connect the SC to LC cables to the patch panel.
 - 1. Above the rack, select **Front** to switch to the front view of the rack.
 - 2. From the Selected Component pane:
 - Drag the *Fiber Optic SC Connector (A)* to port 23 on the fiber patch panel.
 - Drag the *Fiber Optic SC Connector (B)* to port 24 on the fiber patch panel.
- 4. Connect the power adapter to the media converter, and then plug it into a critical load bank outlet on the UPS using the adapter on the shelf.
 - 1. From the Shelf, drag the *Power Adapter, AC to DC* to the DC power port on the media converter.
 - 2. From the Select Connector pane, select **DC Power Connector**.
 - 3. Above the rack, select **Back** to switch to the back view of the rack.
 - 4. Under Shelf, expand **Adapters**.
 - 5. Drag the C14 Power Adapter to an open critical load bank outlet on the rack UPS
 - 6. Under Partial Connections, select the Power Adapter, AC to DC.
 - 7. From the Selected Component pane, drag the *AC Power Adapter* to the C14 Power Adapter installed in the UPS.

The lights on the media converter should turn on.

- 5. Navigate to any workstation on Floor 1 to confirm internet connectivity.
 - 1. From the top left, select **Building A**.
 - 2. Under Building A, select Floor 1.
 - 3. Select a workstation (such as Office1).
 - 4. From the notification area, right-click the *Network* icon and select **Open Network** & Internet settings.
 - 5. Verify that the workstation has internet connectivity.