## Complete this lab as follows:

- 1. Install the SFP Transceiver (LC) in the networking closet on Floor 1.
  - 1. Under Shelf, expand the **Adapters**.
  - 2. Drag the SFP Transceiver (LC) to the SFP 2 port on the switch.
- 2. Connect the fiber cable to the switch.
  - 1. Under Shelf, expand Cables.
  - 2. Select Cable, Fiber, SC to LC.
  - 3. From the Selected Component pane:
    - Drag Connector, Fiber, Duplex LC Multi-mode, Male to the SFP LC port (plugged into SFP2) on the switch.
    - Drag the **Fiber Optic SC Connector (A)** to port 3 on the fiber patch panel.
    - Drag the **Fiber Optic SC Connector (B)** to port 4 on the fiber patch panel.
- 3. Access the networking closet on floor 2.
  - 1. From the top left, select **Floor 1**.
  - 2. Under Building A, select Floor 2.
  - 3. Under Networking Closet 2, select **Hardware**.
- 4. Connect the fiber cable to switches on Floor 2.
  - 1. Under Shelf, expand **Adapters**.
  - 2. Drag SFP Transceiver (LC) to an open SFP port on the switch.
  - 3. Under Shelf, expand Cables.
  - 4. Select Cable, Fiber, SC to LC.
  - 5. From the Selected Component pane:
    - Drag the Connector, Fiber, Duplex LC, Multi-mode, Male to the SFP port.
    - Drag the **Fiber Optic SC Connector (A)** to port 1 on the fiber patch panel.
    - Drag the **Fiber Optic SC Connector (B)** to port 2 on the fiber patch panel.
- 5. Plug the switch on Floor 2 into a bank 1 critical load outlet on the UPS.
  - 1. Above the rack, select **Back** to switch to the back view of the rack.
  - 2. Under Shelf, select AC Power Cable.
  - 3. From the Select Connector pane:
    - Drag AC Power Connector (Female) to the AC port on the back of the switch.
    - Drag the AC Power Connector (Male) to an open bank 1 critical load outlet.
  - 4. Above the rack, select **Front** to switch to the front view and confirm that the network switch has power.
- 6. Verify that there is an internet connection for any Floor 2 computer.
  - 1. From the top left, select Floor 2.
  - 2. Select any of the *computers* on Floor 2.
  - 3. Right-click **Start** and then select **Settings**.
  - 4. Select **Network & Internet**.

The image shown should indicate a connection to the internet.